

RESTORE SETUP PARAMETERS to FACTORY DEFAULTS

General Description

The SC2000 allows an operator to Restore the Setup Parameters back to their original Factory Default values as when the unit was new.

The Restore can be performed from the front of the SC2000 by holding down certain Pushbuttons.

The following will not be affected by the Restore function:

- Analog I/O Calibration - Analog Inputs: AIX1 & A1 - A4
 - Analog Outputs: AOX1 & AO1 - AO4
- Security Setup Parameters - Security Code Setup: SCS1 - SCS3
 - Parameter Write Access Mode: S.01 - S.02
 - Parameter Write Access Relock Delay: S.03

Restore Parameters

On the front of the Controller **Press** and **Hold down** for **ten seconds** the following three pushbuttons:

Up Pushbutton Down Pushbutton Level Pushbutton

After holding the three pushbuttons down for 10 seconds the Restore function will start.

The Numerical Display on the front of the Controller will show the percent completion (0% - 100%).

Do not remove electrical power until the Controller has complete the Restore function.